

ZTW User Manual Of LED Program Card

Specification:

1. Size: 70.0mm*45.0mm*13.0mm(L*W*H)
2. Weight: 23.0g

How to Use the LED Program Card:

1. ZTW Program card with LED display is easy to use and convenient to carry. All of the programmable functions are shown on the program card.
2. Turn on the ESC. Remove the signal wire and plug it into the top-socket on the program card, wait for 2 seconds until the LED is on.
3. If ESC is not connected with the batteries, the program card should be connected with other power supply, the range of power supply is within 5.0-6.3V.
4. Press the button "Menu" on the program card and circularly select each programmable function .At that time the number of programmable function will be displayed on the left of the LED, the current value will be displayed on the right side. Then press the button "Value" to change the value and press the button "OK" to confirm. At the same time the Red indicating LEDs of both program card and the ESC blink. Turn off the ESC, the modified settings will be save in the ESC`s memory.
5. Press the button "Reset" to restore the default settings.



Shenzhen ZTW Model Science & Technology Co., Ltd

ADD: 5/F B , Block A4 , Anle Industrial Estate , St. Hangcheng , Gushu , Baoan , Shenzhen , Guangdong ,

P. R China, 518001

TEL: +86 755 29120026, 29120036, 29120056

FAX: +86 755 29120016

Http://www.ztwoem.com

Email:sales@ztwoem.com